



# OC-SS-39

## Transfer shower w/ seat on right, grab bars at left

### 62050115



#### Features

- ½" (12.7 mm) threshold.
- Durable swirl-gloss finish.
- Center drain.
- Three-piece tongue-and-groove walls with snap-together installation.
- Fold-down seat with stainless steel supports on right, grab bars at left.
- Type A and B multifamily dwellings: Showers will comply with ICC ANSI A117.1 Standards section 1104.11.3.1.3.3 and the Fair Housing Act Accessibility Guidelines when installed per Requirement 6 (Reinforced walls for grab bars) of the Accessibility Guidelines.

#### Installation

- Alcove.
- Caulk required for proper installation.

#### Recommended Products/Accessories

- K-23726 Drain treatment
- K-23733 Vikrell® cleaner

#### Included Components

Product consists of:

- 62055115 39-3/8" x 65-1/4" seated shower end wall set w/ grab bar on left
- 62051100 39-5/8" x 39-3/8" shower base
- 62052113 39-3/8" x 65-1/4" transfer shower with back wall





#### Codes/Standards

- CSA B45.5/IAPMO Z124
- ASTM E162
- ASTM E662
- HUD, UM Bulletin 73

See website for detailed warranty information.

#### Available Colors/Finishes

*Color tiles intended for reference only.*

Color	Code	Description
	0	White
	96	KOHLER Biscuit

1-800-STERLING (1-800-783-7546)

Kohler Co. reserves the right to make revisions without notice to product specifications.

For the most current Specification Sheet, go to [www.sterlingplumbing.com](http://www.sterlingplumbing.com).



**OC-SS-39**  
Transfer shower w/ seat on right, grab bars at left  
**62050115**

### Technical Information

All product dimensions are nominal.

Installation: Three-wall alcove

Drain location: Center

### Notes

Install this product according to the installation instructions.

1/2" minimum finished floor thickness required.

Studs should be positioned as shown.

Backerboards and fasteners protrude beyond the back wall 1-1/2" (38 mm). If installing this product against wall board, 1-1/2" (38 mm) furring strips installed over the wall board are recommended. The stud pocket depth of 40-5/8" (1032 mm) will need to be increased by the combined thickness of the wall board and furring strips.

Drain cutout in subfloor to be 10-1/2" (267 mm) per rough-in illustration as shown to allow the backside of the drain to sit below the subfloor surface.