



Standard Wax Gasket with
Brass Closet Bolt Kit #87760

SPECIFICATION

Install Water-Tite's Standard Wax Gasket with Brass Closet Bolt Kit which is a 100% pure wax gasket for setting all floor outlet toilet bowls. The gasket shall form a water tight, gas tight and odor tight seal. Fits 3" and 4" waste lines. Meets federal specification TT-P-1536A and Buy American Act. Includes two 1/4" x 2-1/4" brass bolts, two brass plated washers, two brass plated nuts and two plastic stand-up washers.

INSTRUCTIONS

1. Be sure the wax ring is at room temperature (about 70°F). If wax ring is too cold a good seal may not be made or the toilet bowl could crack while making the installation.
2. With the toilet bowl upside down on a protective pad or blanket, place the wax ring around the discharge opening. Press firmly to assure adhesion when the toilet is inverted.
3. Using IPS Corporation's Soft Putty make a putty ring about 1 inch high around the outside rim of the toilet. This will make a seal between the toilet rim and the floor.
4. Carefully set toilet down on bolts and twist bowl slightly to spread wax and putty to make a tight seal. Tighten bolts carefully to prevent breaking the bowl.

	Product Code #	Product Descriptions	Model Number
	87760	Standard Wax Gasket w/Brass Closet Bolt Kit	RWG3



www.ipscorp.com watertite@ipscorp.com

500 Distribution Parkway, Collierville, TN 38017, USA ■ TEL: 901-853-5001 ■ WATS: 800-888-8312 ■ FAX: 901-853-5008