



# ***INSTALLATION***

---

*The following are detailed installation instructions for the PipeSeal.*

1. Independently support the pipe through the penetration and center.
2. Wrap the PipeSeal around the pipe and connect the ends by slipping the bolt through the holes. Be sure all the bolt heads are accessible by facing the outside.
3. Slide the seal into the penetration space. Pre-tighten the seals slightly if necessary.
4. Floor or ceiling F2HR applications must be recessed 1/2" into the hole on the ceiling side.
5. Gradually tighten the bolts in a clockwise fashion starting at the 12 O'clock position. Tighten each bolt 2-3 turns at a time. Continue, making 5-9 passes, until uniformly compressed. Do not cross tighten.
6. For Firestop systems using the F2HR Seal, see the sheets on pages 10-12 for proper application.

