

INSTALLATION:

1. Turn off the water supply, and drain the toilet tank.
2. Remove the S-hook from the trip arm. Note the S-hook location.
3. Rotate the existing flush valve counterclockwise 45° and pull to remove. Discard the flush valve, flapper, and gasket. Clean the tank surface around the hole.
4. Wet the gasket to ease installation.
5. Firmly press the flush valve into the notched hole at a 45° angle, and rotate until the flush valve is vertical. Be sure to insert all three flush valve tabs into the hole notches.
6. Install the S-hook to match the location of the original. Attach the S-hook to the trip arm.
7. Turn on the water supply, and flush the toilet several times to ensure proper operation.

