

### Faucet



**Model No.**


93.600

**UPC**

6 71031 00232 7

Chrome finish, 4" center set brass faucet. 7" swing spout with aerator, level handles, replaceable seats and stems. Aerator or hose end.

### Faucet Block



**Model No.**

20.600

**UPC**

6 71031 00031 6

Used when water supply lines are above the tub. Mounts to tub shelf when using a clamp-on faucet.

### HandiFlo™ Fitting



**Model No.**


94.700

**UPC**

6 71031 00287 7

Dispenses water from washing machine discharge hose into laundry tub. Eliminates draping washer machine hose over back/side wall of laundry tub and conceals discharge hose. Mounts to back or side wall of laundry tub, includes mounting hardware.

### Top Cover / UTILATOP®



**Model No.**

92.200 Top Cover (White)

92.206 Top Cover (Almond)

92.201 Top Cover (Biscuit)

19.204A UTILATOP® (White)

**UPC**

6 71031 00292 1

6 71031 00401 7

6 71031 00402 4

6 71031 00380 5

**Fits**

91 & 94 DURATUB®

91AL

91BT

19F, 19W, 18F, 18W

Completely covers tub to create additional counter space. UTILATOP® supports up to 40 lbs.

