

⚠ CAUTION: Risk of product damage.
Do not overtighten the aerator assembly.

1. Assemble the aerator components as shown, and hand-tighten into the faucet.
2. Turn on the water. Slowly tighten the aerator assembly until leakage past the threads stops.

