

Capacity	-018	-024	-030	-036	-041	-042	-047	-048	-059	-060
Table 1. Normal Operating Pressures¹										
°F(°C) ²	TXV System - Liquid Line (± 10 psig) / Suction Line (± 5 psig)									
65 (18)	230 / 137	230 / 133	227 / 135	230 / 136	219 / 142	224 / 136	216 / 133	221 / 130	213 / 125	224 / 128
75 (24)	264 / 139	262 / 138	259 / 139	267 / 140	256 / 144	262 / 140	250 / 139	257 / 136	247 / 132	257 / 133
85 (29)	308 / 142	303 / 142	301 / 141	311 / 142	299 / 147	305 / 143	293 / 142	300 / 141	288 / 136	301 / 136
95 (35)	361 / 144	351 / 144	349 / 143	358 / 145	346 / 149	353 / 145	339 / 144	346 / 145	337 / 139	349 / 139
105 (41)	414 / 146	402 / 146	401 / 146	409 / 146	396 / 151	405 / 148	390 / 147	399 / 148	387 / 142	402 / 142
115 (45)	474 / 148	461 / 148	461 / 149	470 / 150	452 / 154	462 / 150	448 / 150	454 / 150	443 / 144	459 / 145
°F(°C) ²	RFC System - Liquid Line (± 10 psig) / Suction Line (± 5 psig)									
65 (18)	234 / 135	234 / 126	228 / 133	236 / 128	---	228 / 129	---	227 / 125	---	225 / 121
75 (24)	266 / 139	265 / 132	262 / 137	274 / 135	---	264 / 137	---	262 / 133	---	260 / 129
85 (29)	304 / 143	305 / 138	302 / 141	315 / 140	---	307 / 142	---	303 / 139	---	301 / 135
95 (35)	348 / 147	350 / 143	346 / 145	362 / 145	---	352 / 147	---	349 / 144	---	347 / 140
105 (41)	402 / 151	401 / 147	394 / 148	414 / 148	---	401 / 151	---	399 / 148	---	369 / 144
115 (46)	453 / 154	455 / 151	449 / 152	471 / 152	---	455 / 155	---	453 / 152	---	450 / 147

Table 2. Approach (APP) Values³ -TXV System - °F (°C) ± 1°F (0.5°C)										
65 (18)	2 (1.1)	1 (0.5)	2 (1.1)	7 (3.9)	7 (3.9)	7 (3.9)	3 (1.7)	6 (3.3)	5 (2.8)	4 (2.2)
75 (24)	1 (0.5)	3 (1.7)	4 (2.2)	8 (4.4)	7 (3.9)	8 (4.4)	4 (2.2)	6 (3.3)	6 (3.3)	4 (2.2)
85 (29)	1 (0.5)	4 (2.2)	5 (2.8)	9 (5.0)	7 (3.9)	8 (4.4)	4 (2.2)	7 (3.9)	6 (3.3)	4 (2.2)
95 (35)	1 (0.5)	4 (2.2)	4 (2.2)	9 (5.0)	7 (3.9)	7 (3.9)	4 (2.2)	7 (3.9)	6 (3.3)	4 (2.2)
105 (41)	1 (0.5)	3 (1.7)	4 (2.2)	8 (4.4)	7 (3.9)	7 (3.9)	4 (2.2)	7 (3.9)	5 (2.8)	4 (2.2)
115 (45)	0 (0)	3 (1.7)	4 (2.2)	8 (4.4)	6 (3.3)	7 (3.9)	5 (2.8)	6 (3.3)	5 (2.8)	4 (2.2)

Table 3. Subcooling (SC) Values⁴ -TXV System - °F (°C) ± 1°F (0.5°C)										
65 (18)	12 (6.7)	13 (7.2)	11 (6.1)	7 (3.9)	4 (2.2)	5 (2.8)	6 (3.3)	5 (2.8)	4 (2.2)	8 (4.4)
75 (24)	11 (6.1)	10 (5.6)	7 (3.9)	5 (2.8)	4 (2.2)	4 (2.2)	5 (2.8)	5 (2.8)	3 (1.7)	7 (3.9)
85 (29)	13 (7.2)	8 (4.4)	7 (3.9)	5 (2.8)	4 (2.2)	5 (2.8)	6 (3.3)	4 (2.2)	3 (1.7)	7 (3.9)
95 (35)	13 (7.2)	9 (5.0)	7 (3.9)	5 (2.8)	5 (2.8)	5 (2.8)	6 (3.3)	4 (2.2)	4 (2.2)	8 (4.4)
105 (41)	14 (7.8)	9 (5.0)	8 (4.4)	6 (3.3)	5 (2.8)	6 (3.3)	6 (3.3)	5 (2.8)	4 (2.2)	8 (4.4)
115 (46)	15 (8.3)	10 (5.6)	9 (5.0)	6 (3.3)	5 (2.8)	6 (3.3)	6 (3.3)	6 (3.3)	5 (2.8)	8 (4.4)

¹ Typical pressures; indoor evaporator match-up, indoor air quantity and evaporator load will cause the pressures to vary.
² Temperature of air entering outside coil.

³ Approach = Liquid Line Temperature minus Outdoor Ambient Temperature
⁴ Subcooling = Saturation Temperature minus Liquid Line Temperature

AIRFLOW CHECK - Both airflow and refrigerant charge must be monitored for proper system set-up. It may be necessary to alternately check and adjust the airflow and the refrigerant charge.

NOTE: Be sure that filters and indoor and outdoor coils are clean before testing. To determine temperature drop across indoor coil (Delta-T), measure the entering air dry bulb (DB) and wet bulb (WB) temperatures at the indoor coil. Find Delta-T in table 4. Measure coil's leaving air DB and subtract that value from entering air DB. The measured difference should be within ±3°F (±1.8°C) of table value; if too low, decrease the indoor fan speed (refer to indoor unit for information). If the Delta-T is too high, increase the indoor fan speed. Repeat charging procedure and Delta-T (air flow adjustment) procedure until both are correct.

Example: Assume entering air DB - 72, WB - 64, leaving DB - 53. Therefore, Delta-T should be 15 (per table); delta across coil is 72 - 53 or 19 (which is 4°F higher than table value). Action necessary: increase fan speed.

Dry bulb temperature of air entering indoor coil (°F)

Table 4. Evaporator Coil Delta-T

80	24	24	24	23	23	22	22	22	20	19	18	17	16	15
78	23	23	23	22	22	21	21	20	19	18	17	16	15	14
76	22	22	22	21	21	20	19	19	18	17	16	15	14	13
74	21	21	21	20	19	19	18	17	16	16	15	14	13	12
72	20	20	19	18	17	17	16	15	15	14	13	12	11	10
70	19	19	18	18	17	17	16	15	15	14	13	12	11	10
°F	57	58	59	60	61	62	63	64	65	66	67	68	69	70

[Wet bulb temperature of air entering indoor coil]

Table 5. RFC Sizes

Capacity	-018	-024	-030	-036	-041	-042	-047	-048	-059	-060
RFC Size	0.052	0.060	0.067	0.072	TXV	0.081	TXV	0.083	TXV	0.097

Table 6. Superheat Value (RFC)* ± 1°F (0.5°C)

Outdoor Temp (°F)		65	70	75	80	85	90	95	100	105
C A P A C I T Y	-018	21	21	21	19	18	16	13	9	1
	-024	25	25	24	23	22	21	19	16	13
	-030	20	20	19	17	15	13	9	7	4
	-036	26	25	24	22	20	18	15	12	10
	-042	25	24	22	20	17	15	12	7	6
	-048	27	26	24	22	19	16	12	8	3
-060	28	26	24	21	18	14	10	6	4	

*Suction line saturation temperature minus suction line temperature. All measurements are at the service valves and are based on 80db / 67wb indoor temperature.